


Wintal[®]

User Manual


DAB / FM Digital Radio



DAB10W

Please read this user manual carefully before using the receiver

LOCATION OF CONTROLS



- | | |
|--------------------|---------------------------|
| 1. Speaker | 10. DAB/ FM Key |
| 2. LCD Display | 11.◀ Previous Key |
| 3. ON/ OFF Key | 12. Select Key |
| 4. Display Key | 13.▶▶ Next Key |
| 5. Scan Key | 14. 3.5mm Earphone Socket |
| 6. Preset Key | 15. DC Power Socket |
| 7. Menu Key | 16. Aerial Input |
| 8. Volume Down Key | |
| 9. Volume Up Key | |

1. Switching your radio on for the first time

1. Switching your radio on for the first time

1.1 Power Supply

1.1.1 Main Adaptor (supplied with the package). Connect the mains adaptor to the DC power socket of the radio to the wall socket.

1.1.2 Battery (not supplied). Open the battery door and insert 4 "AA " size alkaline batteries. Remark: Insert batteries correctly. Pay attention to the +/- Pole.

1.1.3 Extend the telescopic aerial as far as it can go.

1.1.4 Press the Power button to turn on the radio. The LCD backlight will light up during the operation of the radio. The radio will automatically show:



WELCOME TO
DIGITAL RADIO

Your Radio will return to the mode that it was last used in (DAB/FM) . If you were listening to a DAB station before then this station will be automatically selected.

Note: Always make sure that the aerial is extended to ensure the maximum signal strength and the best possible sound quality.

1.2 Adjusting the volume

Press the "Vol" up to increase the volume and the "Vol" down to decrease the volume. Press and hold the "Vol+" or "Vol-" to progressively increase or decrease the volume.

1.3 Changing stations

1.3.1 If you are not already in DAB mode, Press the "DAB/FM" button to go to DAB mode. Then you can press "DAB/FM" button again to go to FM mode.

1.3.2 Press the "◀◀" or "▶▶" button, to scroll through the stations. By default, the stations are listed in numerical and then alphabetical order.

1.3.3 In DAB mode, When the station that you would like to listen to is displayed, press the "Select" button. "Connecting..." will be displayed whilst your radio tunes to your selected station.

1.3.4 In FM mode, the radio will tune to your selected station automatically.

1.4 Scanning for stations

With DAB radio, additional stations and services regularly become available so it's a good idea to carry out a manual scan every now and then to make sure that you have the most up to date station listing stored within the memory of your radio. If you have moved your radio to another location, eg: if you go on holiday, then it" s also a good idea to carry out a manual scan.

1.4.1 If you are not already in DAB mode, Press the "DAB/FM" button to go to DAB mode.

1.4.2 Press the "Scan" button to begin a full search for stations. The display will change to "scanning..." and the number of stations found during the scan will be displayed. A full scan takes approximately 1 minute but can take up to 3 minutes.

1.5 Storing a station preset

Your radio can store up to 10 DAB stations and 10 FM stations in its preset memories for instant access to your favourite stations.

1.5.1 Tune your radio to the station that you wish to preset (see changing stations, 1.3).

1.5.2 Hold the "Preset" button. The display will change to "Preset X" where "X" is the number of the preset (1-10).

1.5.3 Using the "◀◀" or "▶▶" button, select the preset number that you would like to store the station to. Press and hold the "Select" button to store the station.

Note:

1. If there is already an existing DAB or FM station stored under a preset, it will be overwritten when you store the new station.
2. When you store DAB radio station presets, these do not overwrite your FM station presets.

1.6 Tune to a preset station

1.6.1 Briefly Press the "Preset" button.

1.6.2 Use the "◀◀" or "▶▶" buttons to scroll through the station presets.

Press "SELECT" when you see the station that you would like to listen to. The radio will instantly tune to that station and begin to play.

Note: If no station has been stored under the preset, the display will change to "Preset Empty" and then revert to the previously selected station after a few seconds.

1.7 Station Display Symbols

You may see the following symbols displayed alongside a station name. Normally you will see these symbols under DAB mode.

- ? station is not available/not active. This could be used if you try to tune into a secondary service/station at a time when it is not transmitting.
- >>> after the station name, this is a primary station with secondary services eg: a sports station may add extra commentaries at certain times of the day
- <<< before the station name, this is a secondary station

1.8 Display information

When listening to a station you can change the information that will appear on the second line of the display. To do this operation, press the "Display" button repeatedly to move through the display options.

There are eight different types of information that are sent by the broadcaster as below:

Dynamic Label Segment (DLS) - this is scrolling text information supplied by the broadcaster. Information could be the name of an artist or music title, DJ's name, contact details for the radio station etc.

Program Type (PTY) - such as "Rock", "Pop", "Talk" or "News".

Multiplex Name - displays the broadcasting area and collection of radio stations on this frequency eg: BBC National DAB, Digital 1 Network.

Channel and Frequency - eg: 12B 225.64 MHz

Signal Error - The information provided gives details of the signal error rate, shown as a number between 0 - 99. It will not be possible to satisfactorily listen to a radio station with a signal error rate of 30 or above. Try adjusting the aerial or relocating your radio to improve reception.

Signal Information - Stereo or Mono and the data rate at which the signal is being transmitted.

Time - supplied by the broadcaster.

Date - supplied by the broadcaster.

Remark: In FM mode, there will no the display of **Channel Frequency**, **Signal Error** and **Signal Information**, but has additional "Stereo" and "Mono" information.

2. Using the Menu

The "MENU" button enables you to change some of the default settings of your Radio, so that it works just the way you want it to. Use "Select" to confirm your choose, use "◀◀" or "▶▶" to scroll through the menu list.

2.1 In DAB mode, the Main menus are as below

2.1.1 Station List

All the stations will list out under the Statio List, you can choose the listing order you want under the "Station Order" menu.

2.1.2 Full Scan

Full Scan searches the all the stations

2.1.3 Manual Tune

Using the manual tune feature, you can select a specific digital radio channel frequency and then manually adjust the aerial, or the location of the radio, to get the strongest possible signal for that channel in your location.

2.1.3.1 Press the "Menu" button to enter the default settings menu.

2.1.3.2 Use the "◀◀" or "▶▶" button to display "Manual tune" and press "Select" .

2.1.3.3 Use the "◀◀" or "▶▶" button to scroll through the digital radio frequencies and Preset "Select" . An empty ☐ will appear on the first line of the display to indicate the minimum signal strength for acceptable listening. The row of solid rectangles indicate the actual signal strength that you are receiving. The stronger the signal, the further to the right the row of solid rectangles will be.



Note: If only an empty ☐ is displayed, you are not receiving any signal at all for that particular digital radio channel in your area.

2.1.3.4 Adjust the position of the aerial on the radio, to obtain the maximum signal strength and press "Select" to exit back.

2.1.4 DRC(Dynamic range control)

The dynamic range for each radio programme is set by the broadcaster for each radio station and may be different for the types of programme broadcast, such as pop or classical music or a chat show. The dynamic range control signal is transmitted in parallel with the audio signal for each programme and with your Touch DAB radio you can use this control signal to expand or compress the dynamic range (the difference between the loudest and quietest sounds) of the reproduced audio signal. Changing the dynamic range can affect the "loudness" and/or "quality of sound" of the programme that you hear so that it will be more suited to your listening conditions and your own personal listening requirements e.g. in a noisy environment, where quiet sounds might be swamped, setting the compression to maximum will "boost" the quiet sounds, whilst keeping the loudest sounds at their original level.

There are 3 levels of compression:

DRC off no compression. This is the default setting.

DRC high - maximum compression.

DRC low - medium compression.

2.1.4.1 Press the "Menu" button to enter the default settings menu.

2.1.4.2 Use the "◀◀" or "▶▶" button to display "DRC" and press "Select" The current DRC value will appear on line 2 of the display.

2.1.4.3 Use the "◀◀" or "▶▶" button to scroll through the 3 levels of compression, which will appear on line of the display.


2.1.4.4 Press "Select" to confirm your compression setting.

2.1.5 Factory Reset

You can reset your radio and restore all of the original factory settings

Note: If you reset your radio all of your DAB and FM station presets will be deleted.

Press "Select" . The display will change to



Use "Previous" and "Next" to change your choose on <No> and <Yes>, just press Select button to confirm your choose on <Yes>, then return the radio to its original factory settings. The display will change to "Restarting..." , followed a few seconds later by "Welcome to Digital Radio" and will begin scanning for stations. If you decide not to reset your radio at this point, pls press "Menu" to return to the previous play mode.

2.1.6 SW version

Choose this menu to see the SW version.

2.2 In FM mode, the Main menus are as below

Check that your radio is in FM mode. You will see "FM" or "RDS" to the far right of line 1 of the display together with a radio frequency e.g.: 89.60MHz or station name. When your radio is in FM mode it can receive Radio Data System or "RDS" information if this is being

transmitted by the broadcaster. RDS information will often include the station name, detail about the programme and the current time. If you were listening to an FM station when you switched the radio off then this station will be automatically selected when you switch the radio back on.

Note: With FM radio it may be necessary to "fine tune" each station by rotation the "Tune" button. If reception is still poor adjust the position of the aerial or try moving the radio to another location.

2.2.1 Scan Setting

There are two scan types, the "Strong stations" and "All stations", Use the "◀◀" or "▶▶" button to choose the one you want, then press select to confirm it. Then return to menu mode to scan the stations.

2.2.2 Audio Setting

There are two audio types, the "Forced mono" and "Stereo allowed"

2.2.3 Factory Reset

Please refer to 2.1.6

2.2.4 SW version

Please refer to 2.1.7.

Q & A

If you are experiencing problems with your DAB radio there are some quick and easy checks that you can do, which may help to solve the problem.

Radio reception is poor

- Please check that the aerial is extended for the maximum signal strength and improved reception.
- Use the manual tune (see 2.2), to adjust your aerial for the best reception.
- Try moving your radio to an alternative location to see if the reception improves Please remember to scan for DAB stations again once you have moved your radio See 2.2
- Check that you do not have other electrical equipment too close to your radio, causing interference.
- Visit www.digitalradionow.com for information about DAB reception in your area.

No sound

- Adjust the volume using the "Vol+" button
- Please check that the mains power lead is connected at the back of the radio and the mains power wall socket is switched on



CUSTOMER CARE CENTRE



- 1 THIS PRODUCT IS WARRANTED FOR 12 MONTHS FROM THE DATE OF PURCHASE.**
Subject to the conditions of this warranty, the Customer Care Centre will perform necessary service on the product without charge for parts, or labour if, in the opinion of the manufacturer/ manufacturer's agent, the product is found to be faulty within the warranty period.
- 2** This warranty only applies if the product has been installed and used in accordance with the manufacturer's recommendations (as noted in the operating instructions) under normal use and reasonable care. The warranty covers normal domestic use only and does not cover damage, malfunction or failure resulting from use of incorrect voltage, accident, misuse, neglect, build-up of dirt or dust, abuse, mis-adjustment of customer controls, mains supply problems, thunderstorm activity, infestation by insects or vermin, tampering or repair by unauthorised persons (including unauthorised alterations), exposure to abnormally corrosive conditions or any foreign object or matter having entered the product.
- 3** If warranty service is required you should:
 - Telephone the Customer Care Centre on 1300 662 946
 - Provide a copy of your purchase receipt that shows retailers identity and date of purchase.
 - Send or bring the product to your Customer Care Centre.
Please note that freight to and/or from your Customer Care Centre must be arranged by you.
- 4** The warranties hereby conferred do not extend to any costs associated with the delivery, handling, freighting or transportation of the product or any part thereof or replacement of and do not extend to any damage or loss occurring during, or associated with transit.

**THIS WARRANTY CARD AND THE PURCHASE DOCKET
(OR SIMILAR PROOF OF PURCHASE)
SHOULD BE RETAINED BY THE CUSTOMER AT ALL TIMES**

**TROUBLE SHOOTING HELP LINE
1300 662 946**

Customer Care Centre
562 Spencer Street, West Melbourne
VICTORIA 3003

Wintal®
Digital Living